


WINTER

To turn the heating on:

Press the **HEAT** button a few times until the *arrow on the right* points to **ON**.



To turn the heating off:


First purge the building with cold air:

Press the **PURGE** button a few times until the *arrow on the left* points to **ON**.




Wait for 15 minutes.

Press the **PURGE** button a few times until the *arrow on the left* points to **TIMER**.



Then turn the the system off:

Press the **HEAT** button a few times until the *arrow on the right* points to **TIMER**.



On Sunday mornings, the timer will turn the heating on and off, and then purge automatically.